





A robust solid-state reference electrode and its application in environmental monitoring

David Macedo, Dylan Marley, Daniella Caruso, Tony Kilpatrick, Stephen Peacock, Luda Malishev, Krishnan Murugappan



OFFICIAL


Sensor Development Team (Mineral Resources)



OFFICIAL

Potentiometric sensor background

Combination sensor (pH, ISE, ORP)



$E_{\text{indicator}}$



$$E_{\text{cell}} = E_{\text{indicator}} - E_{\text{reference}}$$

$E_{\text{reference}}$

Response to analyte
Interference/poor selectivity
Fouling

Stable regardless of solution chemistry
Electrolyte leakage
Poisoning (sulphide, OH^- , etc.)

Reference electrode background




$$E_{\text{Ag}|\text{AgCl}} = E^\circ_{\text{Ag}|\text{AgCl}} - \frac{RT}{F} \ln a_{\text{Cl}^-}$$

- Potential dependent on chloride activity (concentration)
- Potential can also be affected contamination (S^{2-} , OH^- , etc.)
- Frit needs to enable ionic conductivity, but shouldn't be too permeable!



Smith and Stevenson,
Handbook of Electrochemistry (2007)

In-situ recovery (ISR)








Sensor system overview


OFFICIAL




OFFICIAL

Reference electrode design

Liquid filled RE



"Solid state" RE



Smith and Stevenson,
Handbook of Electrochemistry (2007)


ISR trials revealed issues

- Poor polymer strength/electrolyte retention
- Poor adhesion between polymer composite and case
- Potential poisoning from sulphide species in reducing environment



First field trial prototype after one month underground

Recent reference electrode work



Patents

Solid state reference electrode

WO2018201200A1

M Vepsäläinen, C Wood, M Chen, D Acharya, D Macedo

Interference resistant reference electrode

WO2021087572A1

D Macedo, M Vepsäläinen

Publications

An unusually stable solid state Ag|AgCl reference electrode for long term continuous measurements based on a crosslinked poly(vinyl acetate)/KCl composite


D Macedo, M Vepsäläinen, et al. *Electrochimica Acta* (2020)

A sulphide resistant Ag|AgCl reference electrode for long-term monitoring


D Macedo, M Vepsäläinen, et al. *Analyst* (2024)

Electrochemical characterisation


Electrochemical Impedance Spectroscopy




Potentiometric pH sensing




[Ru(NH₃)₆]Cl₃ voltammetry



Mean potential (n=5) in 1 g L⁻¹ Na₂S



μXRF of electrode cross-sections





OFFICIAL

Revised Vesi™ prototype



Solution parameters

ORP

pH

Conductivity

Temperature


Field trials

Ground water

Surface water


Seasonal creeks

Application in Monitoring Wells – Cu ISR



Comparison graph of VESI™ pH data compared to commercial pH probe and manual sampling

Acid mine drainage – Mt Lyell



pH measurement comparison between Vesi™ and manual sampling after ~6 months without calibration



Conclusions

OFFICIAL

- Sacrificial AgCl significantly improves RE longevity in challenging sulphide solutions
- Demonstrates a more general approach to improve reference electrode resistance to various interferant species
- Enables long-term monitoring with limited maintenance, improving feasibility of continuous monitoring

OFFICIAL



Residential waterways
for water utilities



Rumen monitoring



Miniaturised modular
prototype



Thank you

Mineral Resources

David Macedo
Research Scientist

+61 3 9545 2490
david.macedo@csiro.au

Australia's National Science Agency

